



1 YEAR
WARRANTY

MADE IN
USA



User's Guide



WMS-23
(Transmitter)



WMS-23
(Wind Speed
and Direction
Sensor)

Shop online at

omega.com®

Ω OMEGA®

omega.com

e-mail: info@omega.com

For latest product manuals:

omegamanual.info

ISO 9001
CERTIFIED
CORPORATE QUALITY

STAMFORD, CT

ISO 9002
CERTIFIED
CORPORATE QUALITY

MANCHESTER, UK

WMS-23/WMS-23S Current Loop Wind Sensor



OMEGAnet® Online Service
omega.com

Internet e-mail
info@omega.com

Servicing North America:

U.S.A.:
ISO 9001 Certified
One Omega Drive, P.O. Box 4047
Stamford, CT 06907-0047
TEL: (203) 359-1660
FAX: (203) 359-7700
e-mail: info@omega.com

Canada:
976 Bergar
Laval (Quebec) H7L 5A1, Canada
TEL: (514) 856-6928
FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

U.S.A. and Canada: Sales Service: 1-800-826-6342/1-800-TC-OMEGA®
Customer Service: 1-800-622-2378/1-800-622-BEST®
Engineering Service: 1-800-872-9436/1-800-USA-WHEN®

Mexico:
En Español: (001) 203-359-7803
e-mail: espanol@omega.com
FAX: (001) 203-359-7807
info@omega.com.mx

Servicing Europe:

Czech Republic: Frystatska 184, 733 01 Karviná, Czech Republic
TEL: +420 (0)59 6311899
FAX: +420 (0)59 6311114
Toll Free: 0800-1-66342
e-mail: info@omegashop.cz


Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
TEL: +49 (0)7056 9398-0
FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: info@omega.de

United Kingdom:
ISO 9002 Certified
One Omega Drive, River Bend Technology Centre
Northbank, Irlam, Manchester
M44 5BD United Kingdom
TEL: +44 (0)161 777 6611
FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk


It is the policy of OMEGA Engineering, Inc. to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications.



WMS-23 Wind Speed & Direction 4-20 mA Output Circuit and Enclosure



WMS-23 Wind Speed & Direction Sensor

TABLE OF CONTENTS

Section No.	Page No.
1.0 INTRODUCTION	1
1.2 Physical Description	1
1.2.1 The Wind Sensor	1
1.2.2 The Encoder	1
2.0 SPECIFICATIONS	2
3.0 THEORY OF OPERATION	3
3.1 Wind Speed Measurement	3
3.2 Wind Direction Measurement	3
4.0 INSTALLATION	4
4.1 Unpacking	4
4.2 Wind Sensor Installation	4
4.3 Transmitter Installation	4
5.0 OPERATIONAL TESTING	5
5.1 Circuit Board Adjustments	6
6.0 MAINTENANCE	7

Model WMS-23 & WMS-23S Current Loop Wind Sensor Instruction Manual

1.0 INTRODUCTION

The Model WMS-23 Current Loop Wind Sensor measures wind speed and direction and converts each measurement into a 4-20 mA output signal for use by process controls or monitoring systems. External power is not required since the encoding electronics for wind speed and for wind direction are isolated and powered from their respective 2-wire current loops. Omega offers two versions of the wind sensor; the WMS-23 measures both wind speed and direction, while the WMS-23S measures only wind speed. Both models contain two subassemblies; the wind sensor and the signal conditioning electronics assembly.

The WMS-23 Wind Speed & Direction Sensor used with the WS-23 includes a three-cup anemometer and a wind vane. The WS-23S uses the WMS-23 Wind Speed Sensor, which consists of the same anemometer without the wind vane. The sensor is ruggedly constructed using UV-resistant ABS plastic and anodized aluminum parts. The cable connecting the pole-mounted wind sensor to the encoder electronics package is typically 40 feet in length but may be extended for a total length of 250 feet. The encoded current loop signals are capable of being transmitted over distances of up to several miles. The electronics package is supplied inside a gasketed NEMA enclosure.

1.2 Physical Description

1.2.1 The Wind Sensor

The wind sensor is the rotating assembly with the three cup anemometer and wind vane for measuring wind speed and wind direction. The wind vane is mounted onto a common axis with the anemometer and includes a tail fin with a nose weight that provides balance. The wind vane is coupled to an angular encoder that is housed within the sensor's cylindrical weather skirt.

1.2.2 The Encoder

The encoder electronics package is housed within a gasketed NEMA enclosure. The circuitry contains two independent 4-20 mA data channels, one for wind speed and one for wind direction. Each channel receives its power from its respective 2-wire measurement loop.

2.0 SPECIFICATIONS

SENSOR

Wind Speed

Measurement range	0-100 mph (standard) 0-50 m/s, 0-100 knots, or 0-200 km/hr (optional)
Speed constant	1.25 mph = 1 pps 75 mph = 60 Hz (pps)
Transducer type	Reed switch
Speed threshold	0.8 mph
Accuracy	1 mph or $\pm 3\%$

Wind Direction

Range	0-360 Deg Az
Transducer type	Potentiometer, 20k ohms, conductive plastic
Potentiometer gap	5°
Azimuth accuracy	$\pm 3^\circ$
Threshold	1.2 mph
Bearings	Bushing

TRANSMITTER UNIT

Current loop output span	4 to 20 mA, proportioned to 0-100 mph & 0-360° (std)
Supply voltage range	8 to 30 Vdc
2-wire loop interface	Screw terminal block
Interface power	Derived from current loop

GENERAL

Mounting	1" o.d. pipe
Cable	5 Conductor, 24 AWG, Shielded, 40' standard
Dimensions	
WMS-23 (WS/WD)	12" H x 10" W
WMS-23S (WS)	4.5" H x 8.5" W
Electronics enclosure	4.7" H x 4.7" W x 2.25" D
System weight/shipping	5 lbs/7lbs

3.0 THEORY OF OPERATION

3.1 Wind Speed Measurement

The Model WMS-23 wind sensor has been designed to provide measurement of wind speed and wind direction. Wind speed is measured by a rotating assembly of three cups. The three cups are attached onto a central shaft that supports the cups as well as provides a mounting point for the sensor's ball bearing. The ball bearing provides smooth rotation of the cups and helps produce an accurate measurement. The anemometer's precision ball bearing is protected from the weather and has lifetime lubrication. The rotation of the cups is sensed by a magnetically activated switch. The switch is in a fixed position while three magnets are fastened to the rotating cup housing. The number of switch closures per rotation is converted into a frequency that is proportional to the wind speed in miles per hour. The full-scale (20 mA) output of the wind speed channel represents a measurement of 100 mph.

3.2 Wind Direction Measurement

Wind direction is measured by a rotating device as well. The wind vane rotates about its central shaft in response to changes in the wind's direction. The counterweight at the end of the wind vane nose balances the weight of the moving mass over its supporting bearing. It is important that the wind sensor be installed in a location free from any obstructions that would distort the natural flow of air across the sensor. The vane's rotation is transmitted to a stationary potentiometer located inside the sensor housing. As the shaft rotates, the resistance of the potentiometer at its wiper changes. The sensor has been designed to produce an increasing resistance as the wind direction increases from zero to 360 degrees azimuth. From above the sensor this increase in direction will appear as a clockwise rotation of the vane. The opposite is true for a decreasing wind direction. A wind changing from 360 towards zero degrees results in a decrease in resistance and a counterclockwise rotation.

Application of a voltage across the potentiometer allows measurement of the wind direction as a changing voltage. The voltage changes are converted by the encoder circuitry into a proportional 4 to 20 milliampere signal with 4 mA equal to zero degrees and 20 mA equal to 360 degrees. The full-scale span of the direction channel means that the vane nose is pointing toward 360 degrees or North.

The potentiometer used as a direction sensor for wind direction has an arc of resistance discontinuity or "deadband" (typically 5°). The deadband is located between the 360 degree and the 0 degree points (North is indicated by the set screw in the mounting base). Typically, the deadband is centered on the North point. This means that the sensor really does not measure zero degrees but instead starts measuring at 2 to 5 degrees. Similarly, the end of the direction measurement occurs at 355 to 357 degrees and not exactly at 360. When the wind vane is pointing in this region the loop current will be encoded as an full scale value of approximately 20.0 mA.

4.0 INSTALLATION

4.1 Unpacking

Empty the loose packing material from the corrugated shipping container and carefully lift out the wind sensor assembly. Refer to the warranty page at the front of the manual for information regarding returning damaged or incorrect equipment. The tail is normally removed for shipping. Reattach with the 2 screws to the shaft.

The following items should be included in the shipping container for Model WMS-23:

1. Wind Speed & Wind Direction sensor, with 40 feet of cable
2. Transmitter Housing Assembly
3. Instruction Manual

4.2 Wind Sensor Installation

Choose the mounting location for the wind sensor that is free from obstructions. Use extreme care to prevent contact with electrical power lines while erecting the unit. A typical installation will position the wind sensor approximately 33 feet (10 meters) above the highest obstacle within a 990 foot (300 meter) radius of the mounting location. Position the Model WMS-23 sensor onto the end of a 1" o.d. TV mast tubing or a 3/4" Schedule 40 pipe. If the pole is metal it should be electrically grounded to minimize the probability of any lightning damage. Rotate the anemometer on the pole so that the two set screws on the anemometer base are facing North. Magnetic North is adequate for most installations. Should a True North alignment be required, the magnetic declination at the sensor location must be known and applied to the compass reading. Tighten the bottom set screw to fix the directional orientation.

4.3 Transmitter Installation

Mount the transmitter enclosure in a location where it can be conveniently connected to the wind sensor.

Route the sensor signal cable in the most direct manner possible. Avoid sharp corners and edges. Do not crease or fold the cable. The cable must be protected from high winds. Use an appropriate fastener (plastic cable ties, staples, etc.) to secure the cable to its support structure. Use care to avoid puncturing the cable jacket if staples are used to attach the cable to a wooden support.

The standard wind sensor is supplied with 40 feet of cable. In the event that the interconnecting cable needs to be extended, use good splicing techniques and waterproof the splice if it will be exposed to the weather. The 5-conductor cable to the wind sensor may be extended to up to 250 feet in length without degrading the accuracy of the sensor's measurements. The output cable running from the transmitter enclosure for the current loop is not provided with the equipment. The current loop power supplies are also not furnished with the standard unit. The cable and power supplies are required for operation of the equipment and are generally customer furnished items.

I/O connection terminal strips are located on the printed circuit board. Terminal functions along with the corresponding colors of the wind sensor interconnecting cable are shown in the table below. The WS/WD cable supplied is a 5-conductor, 24AWG, shielded, outdoor grade cable.

The WS cable supplied is a 2-conductor, 24AWG, shielded, outdoor grade cable.

Wind Speed and Direction WMS-23 5 conductor

●1	○		Wind Dir. Sig -Green
●2	○		Wind Dir. EXC.- Red
●3	○		Wind Dir. Ref. - Black
●4	○		Wind Speed Ref. - Brown
●5	○		Wind Speed Sig. - White
●6	○		Earth Ground - Shield
●1	○		Wind Direction 4-20 mA Loop +
●2	○		Wind Direction 4-20mA Loop -
●3	○		Wind Speed 4-20mA Loop +
●4	○		Wind Speed 4-20mA Loop -

Wind Speed WMS-23S 2 conductor

●1	○		N/A
●2	○		N/A
●3	○		N/A
●4	○		Wind Speed Ref. - Black
●5	○		Wind Speed Sig. - Red
●6	○		Earth Ground - Shield
●1	○		N/A
●2	○		N/A
●3	○		Wind Speed 4-20mA Loop +
●4	○		Wind Speed 4-20mA Loop -

5.0 OPERATIONAL TESTING

Connect the speed and wind direction 4-20mA, loop circuits to the appropriate locations of the terminal strip of the printed circuit board as shown in the above chart. For test purposes, you may wish to use an unregulated but filtered source of 10 to 24 volts DC power having a precision 100 ohm resistor (preferably $\pm 1\%$ accuracy) connected in series with the supply. The loop powered encoding circuits require the proper polarity of loop current; however diodes are included to protect the circuitry against reversed polarity connections.

Connect the test leads of a digital voltmeter across the resistor to measure the plc loop current. The measured wind speed and direction at several cardinal calibration points are shown in the following table:

Wind Direction (Deg Az)	Wind Speed (mph)	Loop Current (mA)	V _{100Ω} (Volts)
N+	0.0	4.0	0.4
NE = 45°	12.5	6.0	0.6
E = 90°	25	8.0	0.8
SE = 135°	37.5	10.0	1.0
S = 180°	50	12.0	1.2
SW = 225°	62.5	14.0	1.4
W = 270°	75	16.0	1.6
NW = 315°	87.5	18.0	1.8
N-	100	20.0	2.0

5.1 Circuit Board Adjustments

Multiple turn potentiometers located on the printed circuit board are provided for independent gain and offset adjustment for both the speed and direction channels as shown in the table below:

	Offset	Span
Wind Speed	R-33	R-17
Wind Direction	R-26	R-28

The Model WMS-23 normally should not require adjustment of these controls. An exception occurs if for any reason the wind sensor is changed or if the cabling to the wind sensor exceeds 200 feet in length. In these cases the span control of the direction channel may require a slight adjustment.

The wind speed channel does not normally require any adjustments in the field. The wind sensor output signal is a reed switch closure. There are three switch closures for each revolution of the cup assembly. Rotating the cups by hand and using a swift spin will produce a wind speed output of 10 to 20 miles per hour.

6.0 MAINTENANCE

Maintenance of the wind sensor assembly is limited. Periodic but regular inspections of the equipment is necessary to prevent damage due to loose or missing hardware. Wind sensors experience many vibrations due to high velocity winds blowing through the tower and mast support structure. These vibrations can cause mounting hardware to become loose and to fall out. Tighten any loose hardware and replace any missing hardware.

Inspect the sensor cable as well to detect any damage due to wind whipping. Replace any damaged cables immediately, especially if there are exposed wires. Cracked and weathered cable jackets are not usually a problem as long as the cable is securely fastened by wire ties. Check wire ties and replace any that have become loose or that are missing.

Check for damage to the anemometer cups and the vane tail. Replace any cup assembly that has been damaged.

Remove all dust, dirt, mud, bird droppings, etc., that may have been deposited onto the cups and vane tail. Repair or replace bent tails. Check the counterweight of the wind direction sensor. Repair the vane shaft if the counterweight is loose. The counterweight is held in place by epoxy.

Apply several drops of light weight (3-in-1) machine oil or lightly spray WD40 onto the anemometer bearing located just below the cups.

Always look at the wind vane alignment to North. If the alignment is critical, do the check with a compass. Make corrections to the alignment as needed. Always check the alignment after a severe storm with high velocity winds.

Check the equipment that the sensor is connected into. Make sure that there are signals coming from the sensor. Test the signals to be certain that the measurements are accurate.



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2007 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for Process Measurement and Control? **OMEGA...Of Course!** *Shop online at omega.com*

TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- Transducers & Strain Gages
- Load Cells & Pressure Gages
- Displacement Transducers
- Instrumentation & Accessories

FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments